Stick Mixer Model EL003SM

PLACE PICTURE HERE

INSTRUCTION MANUAL

SAVE THESE INSTRUCTIONS

Dear Valued Customer

Thank you for choosing to purchase this appliance, we appreciate your business. We have provided a product, which is value for money.

TECHNICAL INFORMATION

Please make sure that your house installation voltage corresponds to the voltage marked on the unit.

Mains supply:	230-240V ~ 50 Hz – AC only
Rated Power:	120 watts

BEFORE FIRST USE

1. Your appliance has left the factory in good working order in this carton for your protection. Should the carton be damaged or if the product is dropped, damaged, has a malfunction in any way, or if the flexible cord is damaged, immediately contact your retailer for replacement or repair.
2. Carefully unpack your appliance. Make sure you do not discard any packaging material until all parts of the appliance have been found.
3. Carefully wipe the exterior of the appliance with a damp cloth to remove any dust that may have accumulated. Dry with a dry towel. Do not use abrasive cleaners.
   WARNING do not immerse in water or any other liquids.
4. Wash the accessories in warm soapy water. Dry with a dry towel.
5. The appliance is now ready for operation.

OPERATION

- Before using the appliance for the first time, or after long periods of storage, clean the appliance thoroughly. (See BEFORE FIRST USE.)
- Plug the power cord into a suitable mains outlet corresponding to the supply requirements of your appliance.
  Mains supply: 230-240 V~50Hz – AC only
- Your appliance is now ready for use.
- NOTE The first time you use your appliance, there may be a small amount of smoke and smell. This is normal. It is due to a protective coating, placed on the motor to protect the appliance during shipping.
- WARNING Short-term operation. This appliance is designed for short term operation only. After 1 minutes continuous operation, allow to cool completely before re use.
- Avoid contact with moving parts. Keep hands, hair, clothing, as well as spatulas and other utensils away from the blades during operation to reduce the risk of injury to you and / or damage to the appliance.
- This appliance can be used to chop small solid ingredients or to mix liquids. Cut larger ingredients into smaller pieces before placing into mixing bowl or container. If chopping fruits or vegetables, use a container with tall sides.
- Do not put unnecessary strain on the motor by mixing mixtures that do not allow the blades to move freely.
- Place blades into ingredients and turn on. Hold the stick mixer firmly. The mixer will stop once switch button is released.
- During mixing, occasionally use a spatula to scrape mixture from the sides of the bowl to ensure that all ingredients are thoroughly mixed.

CLEANING AND CARING

- Always disconnect your appliance from the mains supply before cleaning.
- Always allow your appliance to cool completely before cleaning.
- Never immerse your appliance in water or other liquids.
- Wipe the exterior of the appliance with a damp cloth. Dry with a dry towel.
- Wash the accessories in warm soapy water. Dry with a dry towel.
- Store your appliance in its original box or in a dry cupboard.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

1. Carefully read these instructions before using your appliance.
2. CAUTION Keep out of reach of children. This appliance is not intended for use by young children or infirm persons. Young children must be supervised to ensure that they do not play with the appliance.
3. Safely dispose of plastic bags and other components of the packaging. They may be potentially dangerous to children.
4. VERY IMPORTANT Do not immerse in water or other liquids or use near washbasins or sinks. Ensure that the appliance does not get wet (water splashes etc.) and do not use it with wet hands.
5. Unplug from mains outlet when appliance is not in use, before attaching or removing accessories, and before cleaning.
6. An appliance dropped or damaged should not be used until examined by a service engineer.
7. Do not permit the mains lead to come in contact with hot objects.
8. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
9. Use this appliance only for its intended use. Use only genuine attachments supplied by an authorised Service-Dealer.
10. The appliance should not be used outdoors, placed near a hot gas or electrical burner or placed in a heated oven.
11. Do not let the cord hang over edge of table or counter.
12. WARNING An appliance should never be left unattended when plugged in.
13. This appliance is intended for household use only and not for commercial or industrial use.
14. If appliance is to be used by a third party, please supply the instruction manual with it.
15. No liability can be accepted for any damage caused by non-compliance with these instructions or any other improper use or mishandling.

CAUTION

Do not attempt to service this appliance yourself. Refer servicing to qualified service personnel.